



## EASYPSV™ APPLICATION INSTRUCTIONS

1. Place EasyPSV™ with the liner side down and cut your design. (DO NOT reverse/mirror your design)
2. Weed excess vinyl.
3. Remove the application tape's paper liner. Place tape on top of EasyPSV™ and burnish with a squeegee.
4. Lift the application tape with EasyPSV™ attached away from the paper liner to expose the sticky adhesive.
5. Place the application tape on your desired object and burnish with a squeegee to fully adhere the design.
6. Gently peel away the application tape, leaving just your EasyPSV™ design on the object.

### EASYPSV™ REMOVABLE

Specifications: Matte finish • 3 mils/76.2 microns • 45° blade

Outdoor Durability	Up to 3 years depending on usage and exposure to elements
Adhesive	Removable, Water Based
Liner	78# Kraft
Minimum, Application Temperature	+40° F
Shelf Life	1 year when stored at 70° F and 50% relative humidity.

Not recommended for use with dishwasher or microwave.

### EASYPSV™ PERMANENT

Specifications: Gloss finish • 3 mils/76.2 microns • 45° blade

Outdoor Durability	Up to 5 years depending on climate and UV exposure.
Adhesive	Permanent, Water Based
Liner	78# Kraft
Minimum, Application Temperature	+40° F
Shelf Life	1 year when stored at 70° F and 50% relative humidity.

Not recommended for use with dishwasher, microwave, or painted drywall.

### EASYPSV™ PERMANENT - GLITTER

Specifications: Smooth gloss finish • 3 mils/76.2 microns • 45° blade

Outdoor Durability	Up to 5 years depending on climate and UV exposure.
Adhesive	Permanent, Solvent Based
Liner	78# Kraft
Minimum, Application Temperature	+40° F
Shelf Life	2 years when stored at 70° F and 50% relative humidity.

Not recommended for use with dishwasher, microwave, or painted drywall.

Recommended Accessories : Vinyl Cutter • Siser® Weeder • EasyPSV™ Application Tape • Siser® Squeegee

